

Handle strips made of solid wood

Instructions for installation

The use of L-profile mouldings as recessed grips is recommended for drawers / doors that are directly below the worktop or cover panel. C-profile mouldings are used between two drawers or between drawer and door.



Planning of furniture with integrated wooden handle mouldings



Measurement of the exact position of the handle



Mark the position



Cut out the side part of the body



Check the fit



Attach using assembly accessories



Glue end caps – view from the outside



View from the inside – handle with end caps



Finished body with oak handles L+C profiles and one sided end